

## MODEL NO. 60164 Doorway Panel

### PARTS LIST

DESCRIPTION	No. REQ'D	PART NUMBER
Doorway Panel	1	301410
Hardware Complete	1	306525
5" O.D. Panel Clamp	4	302099*
1/4" x 3/4" Drive Rivet	4	168449*
3/8" Barrel Nut	4	804804*
3/8" Heavy Hex Nut	4	804200*
3/8" Flat Washer	4	817410*
3/8" x 1 1/2" P.B.H.C.S.	8	812053*

Unless Otherwise Specified, All Units of Measure are Each  
\*Included in Hardware

**Warning:** Small parts and hardware items may present a potential choking hazard. Promptly remove all unused parts from play area. Any bolt end protruding more than two full threads beyond the face of the nut causes risk of clothing entanglement. Promptly cut-off flush, file smooth, and treat to prevent corrosion.

**Note:** Peen Tee-Nuts and Flatwashers to match radius of pipe after assembly is complete.  
**Note:** Loctite (supplied by others) should be used on all threaded hardware.

#### INSTALLATION INSTRUCTIONS:

1. Attach the SuperMax Door Way Panel to the Upright Posts using Panel Clamps (refer to Clamp Sub-assembly sheet for details) using 3/8" x 1-1/2" P.B.H.C.S. with Patch with 3/8" Flat Washers and 3/8" Barrel Nuts as shown in Assembly Drawing.

**IMPORTANT!** Avoid creating any gaps between the components, which fall between 3-1/2" and 9". It has been shown that such gaps create entrapment points, which can trap a child and cause injury.

**Note:** Panels should be positioned so that the top of each panel is at least 38" above the deck surface. If a conflict exists between a panel clamp and an adjacent component's clamp, adjust the panel upward (Never lower than 38" above deck) without exceeding a maximum gap of 3-1/2" between the lower end of the panel and the top edge of the deck.

2. When the assembly is finished and satisfactory, install Drive Rivets in all clamps to ensure clamps cannot slide down posts. See Pipe Clamp sub-assembly sheet. **It is very important that all Drive Rivets be installed before allowing use of the equipment, as clamps are not designed to support substantial weight without them.** Also eliminate sharp points and sharp edges (buring) on installed hardware like bolts, nuts, etc.
3. Install resilient surfacing material within the *use zone* of play structure, in accordance with ASTM specifications F1292 appropriate for the fall height of each structure. Refer to the *Safety Guidelines*.

#### MAINTENANCE PROCEDURE:


Periodically check hardware for tightness, and tighten as necessary. Always check all parts for breakage or wear, and immediately put equipment out of service until any faulty parts found are repaired or replaced. Check for rust or paint loss and touch-up if necessary with paint. Check welded areas and verify integrity. Check for cracks, gouges or breakage on plastic, check for integrity of the plastic, keep plastic clean of any extraneous substances, verify that any deformation does not create entrapment as specified on ASTM F1487-98 section 6. Check periodically resilient surfacing for appropriate depth and remove extraneous materials that could cause injury, infection, or disease. Maintain detailed installation, inspection, maintenance, and repair records for each public-use playground equipment.

## MODEL NO. 60164 Doorway Panel

**NOTE:**

TOP EDGE OF PANEL MUST BE 38" [965mm] OR GREATER ABOVE ELEVATED PLATFORM SURFACE FOR USE BY 5-12 YEAR OLDS.

TOP EDGE OF PANEL MUST BE 29" [736mm] OR GREATER ABOVE ELEVATED PLATFORM SURFACE FOR USE BY 2-5 YEAR OLDS.



TYPICAL ASSEMBLY