

## MODEL NO. 60054 SUPERMAX SPIN AND WIN PANEL

### PARTS LIST

DESCRIPTION	No. REQ'D	PART NUMBER
Spin and Win Panel	1	306534
Hardware Complete	1	306525
5" O.D. Panel Clamp	4	302099*
1/4" x 3/4" Drive Rivet	4	168449*
3/8" Barrel Nut	4	804804*
3/8" Flat Washer	4	817410*
3/8" Heavy Hex Nut	4	804200*
3/8" x 1 1/2" P.B.H.C.S. w/Patch	8	812053*

*Unless Otherwise Specified, All Units of Measure are Each  
\*Included in Hardware*

**Warning:** Small parts and hardware items may present a potential choking hazard. Promptly remove all unused parts from play area. Any bolt end protruding more than two full threads beyond the face of the nut causes risk of clothing entanglement. Promptly cut-off flush, file smooth, and treat to prevent corrosion.

**Note:** Peen Tee-Nuts and Flatwashers to match radius of pipe after assembly is complete.

**Note:** Loctite (supplied by others) should be used on all threaded hardware.

### INSTALLATION INSTRUCTIONS:

1. Attach Panel Clamps to Pre-assembled Spin and Win Panel using 3/8" x 1 1/2" P.B.H.C.S. w/ Patch with 3/8" Flat Washers and Barrel Nuts as shown in the assembly drawing.
2. Fasten Panel Clamps to upright Posts (refer to separate Panel Clamp fastening detail).

Note: Panels should be positioned so that the top of each panel is at least 38" above the deck surface. If a conflict exists between a panel clamp and an adjacent component's clamp, adjust the panel upward (Never lower than 38" above deck) without exceeding a maximum gap of 3-1/2" between the lower end of the panel and the top edge of the deck.

**IMPORTANT! Avoid creating any Gaps between the components, which fall between 3-1/2" and 9". It has been shown that such gaps create entrapment points which can trap a child and cause injury.**

3. Plumb the Spin and Win Panel assembly and tighten Panel Clamp fasteners.
4. When the structure is finished and satisfactory, install Drive Rivets in all clamps to ensure clamps cannot slide down posts. See a Panel Clamp subassembly sheet. ***It is very important that all Drive Rivets be installed prior to allowing use of the equipment, as clamps are not designed to support substantial weight without them.*** Eliminate sharp points and sharp edges (burring ) on installed hardware like bolt, nuts, etc. Install resilient surfacing material under and around all equipment before allowing use. Refer to the *Safety Guidelines*.

### MAINTENANCE PROCEDURE:

Periodically check hardware for tightness, and tighten as necessary. Always check all parts for breakage or wear, and immediately put equipment out of service until any faulty parts are repaired or replaced. Check all decks for Plastisol-coating peeling and touch-up with Plastisol if necessary. Check for holes on deck, clean if necessary. Check periodically resilient surfacing for appropriate depth and remove extraneous materials that could cause injury, infection, or disease. Maintain detailed installation, inspection, maintenance, and repair records for each public-use playground equipment.

## MODEL NO. 60054 SUPERMAX SPIN AND WIN PANEL

